



## INSTALLATION GUIDE

CTS TURBO AUDI B9 Q5/SQ5 FRONT AND REAR SWAY BAR  
UPGRADE



## WHAT IS INCLUDED

1. Front sway bar
2. Rear sway bar
3. Bushings



## NOTES

Always make sure the car is safe to work on. Do not work on a hot motor.

## STEP 1

Start with the front of the vehicle.

Remove the under tray.



## STEP 2

Locate the front sway bar and  
loosen and remove the nut from  
the end link.

You will need to loosen the upper  
front end link as well



### STEP 3

Now remove the sway bar bracket and nuts.



### STEP 4

Remove the sway bar.



## STEP 5

Install the bushings on the front sway bar. We recommend greasing the bushings before install.



## STEP 6

Install the brackets.



## STEP 7

We recommend giving some preload on the suspension before tightening the lower and upper end links.

Next is the rear sway bar.



## STEP 8

Remove the lower end link bolt and sway bar bracket.



## STEP 9

Once you have removed all the bolts. You will need to fish the sway bar out from the left side if the vehicle.

Depending on your vehicle you may need to drop the exhaust a bit to help get the OEM sway bar removed.



## STEP 10

Install the CTS bushings and we recommend greasing the bushings.



## STEP 11

The inside hole is the soft setting and recommended for daily driving.



## STEP 12

Again before tightening the sway bar to the end links we recommend pre-loading the suspension.



## STEP 13

Thats it you are done.

